






| | |
|---|---|
|  | Broadcasting for devices. |
|  | Search devices by IP addresses |
|  | To change password on the Network Control Application. If password is lost, please contact local ViewSonic customer support. |
|  | To update current status on all linked projectors. |
|  | To login selected projector. |
|  | To logout selected projector. |
|  | Help advice on Multiple Network Control. |
|  | Projector is Powered On. |
|  | Projector is Inactive. It could either mean the projector is "Power Off", or projector's network control is set to be RS232 (Please refer to Network Control of the UG, page 18 to link with the project). |
|  | Projector is not login. |
|  | Projector is mute. |
|  | Projector is not login & mute. |
|  | Refreshing in progress. |
|  | |