Release Notes for NovAtel Connect 2.0.1

Products Supports

Connect 2.0.1 supports NovAtel format logs from the OEM6 and OEM7 family.

Note: Some functionality for the OEM6 receivers are not available in Connect 2.0. If those features are required, please continue using Connect 1.8 on Windows 7 (or earlier versions of Windows).

Updates:

- Short Header Messages Support in Logging Control Window and Console Window
- Improved Connection Error Screen & Connection Status messages
- SPAN Wizard: Alignment mode parameters now displayed correctly after Submit.
- Fixed issues with SaveConfig feature in wizards
- Implemented Automatic re-connection when issuing commands that trigger a receiver reset.
- Fixed ‘Applyvehiclebodyrotation' setting not being applied correctly in SPAN Wizard
- Diagonal resize option implemented in Connection Window
- ITK Window refinements and improvements
- Connection Manager behavioral improvements
- Fixed text trimming/overlapping issues at 125% DPI
- Various UI and graphical improvements

Unavailable Features

These windows are not available in Connect 2.0. They are still available in Connect 1.8.

- Advanced tracking window
- Align window
- Clock window
- Compass window
- Heave window
- Plan window
- Plan View All window
- Velocity window

Platforms Supported

Connect 2.0.1 is designed to run on:

- Windows 7 64 bit
- Windows 8.1 64 bit
- Windows 10 64 bit

PC HW Requirements

Recommended PC HW Requirements

• 100GB hard drive space
• 4GB RAM
• Available serial, USB or Ethernet port
• 1920x1080 display resolution
• 64 bit processor
• CPU @ 2GHz or higher
• Windows 7, 8 or 10
• Intel I3

Minimum PC HW Requirements

• 512MB hard drive space
• 2GB RAM
• Available serial or USB port
• 1024x768 display resolution
• 32 bit processor
• CPU @ 1GHz (or higher)
• Windows 7
• Intel P4 2 Core (or higher)