



- After installation, if you try to run the program and read the meter before you have restarted Windows, there will be an error. Make sure you restart after installation.
- If the meter display cannot be read, turn off the meter with the program running, then quit the program. Restart the meter and then the program.
- If the meter display cannot be read or an error occurs when “Start Logging Data” is clicked, make sure you have chosen the correct COM port.