

EBIZ WEIGHBRIDGE SOFTWARE NEW VERSION FEATURES.

DOWNLOAD LINK

<http://www.ebizinfoserves.co.in/ebiz.zip>

userid:admin password:demo

control panel password:demo

YOU CAN CHANGE THE FIELDS NAME FROM THE CPANEL.

IF YOU HAVE TAKEN FIRST WEIGHT IN TARE WEIGHT EG:56788

SO IN SECOND WEIGHT SYSTEM WILL CHECK WEIGHT IN INDICATOR IS SMALLER THAN WEIGHT IN TARE WEIGHT IF ITS TRUE IT WILL AUTOMATICALLY SWAP THE WEIGHT WITH DATE AND TIME. SAME LOGIC APPLIES WITH GROSS WEIGHT.

NO NEED TO PRESS F1 OR F2 WHILE SELECTING VEHICLE FROM PENDING LIST SYSTEM WILL AUTOMATICALLY DETECTS WHERE TO TAKE WEIGHT IN GROSS OR TARE.

SYSTEM WILL ALSO SHOW USER REPORTS WHICH SAYS WHO HAS TAKEN FIRST WEIGHT AND WHO HAS TAKEN SECOND WEIGHT FOR EACH ENTRY.

THERE IS A SLIP UNLOCK FACILITY WHERE AUTHORIZED PERSON CAN UNLOCK THE COMPLETED SLIP AND MAKE CHANGES IN COMPLETED SLIPS IF NEEDED WITH UNLOCK PASSWORD. TO OPEN UNLOCK PASSWORD BOX THERE IS A KEY ASSIGN IN CONTROL PANEL.YOU CAN ASSIGN SEPARATE KEYS TO EACH CUSTOMERS .

TO ENTER GROSS WEIGHT MANUALLY THERE IS KEY ASSIGN TO UNLOCK GROSS WEIGHT BOX IN CPANEL YOU NEED TO PUT CURSOR ON GROSS BOX AND NEED TO PRESS SECRET KEY TO ENTER GROSS WEIGHT MANUALLY.

DELETE PASSWORD, CONTROL PANEL PASSWORD, AND UNLOCK PASSWORD CAN BE CHANGE BY ANYBODY WHO KNOW OLD PASSWORDS OF DELETE, CONTROL PANEL AND UNLOCK.

ONCE THE TARE WEIGHT SAVED NEXT TIME NO NEED TO ENTER TARE WEIGHT FOR THAT VEHICLE SYSTEM WILL TAKE TARE WEIGHT BY SELECTING VEHICLE NUMBER FROM VEHICLE NUMBER LIST.

SMS TICKET USING GSM DONGLE OR INTERNET BASED API(CAN BE ACTIVATE OR DEACTIVATE FROM CPANEL)

RFID TAGS READER(CAN BE ACTIVATE OR DEACTIVATE FROM CPANEL)

GROSS WEIGHT BARCODE(CAN BE ACTIVATE OR DEACTIVATE FROM CPANEL)

MS EXCEL REPORTS(CAN BE ACTIVATE OR DEACTIVATE FROM CPANEL)

SOFTWARE CREATION FOR SPECIFIC DEVICE LIKE PEN DRIVE OR HARD DRIVE.

TRANSPORTER FILED WITH ITS MASTER(CAN BE ACTIVATE OR DEACTIVATE FROM CPANEL)

SOURCE FIELD WITH ITS MASTER(CAN BE ACTIVATE OR DEACTIVATE FROM CPANEL)

DESTINATION FIELD WITH ITS MASTER(CAN BE ACTIVATE OR DEACTIVATE FROM CPANEL)

IN/OUT FILED(CAN BE ACTIVATE OR DEACTIVATE FROM CPANEL)

SIX ADDITIONAL DYNAMIC FIELDS WHEN YOU CRATE THIS FIELDS AND ACTIVATE MASTER FOR THAT WILL BE CREATED AUTOMATICALLY FOR EACH FIELDS(CAN BE ACTIVATE OR DEACTIVATE FROM CPANEL)

IP OR ETHERNET BASED INDICATOR(CAN BE ACTIVATE OR DEACTIVATE FROM CPANEL)

SUPPORTS RS232,USB2SERIAL CONVERTER

SOFTWARE CAN BE USED FOR SMALL SCALES IN FACTORIES IN KG/GRAMS SETTINGS  
CAN BE CHANGED FROM CPANEL.

USB CAMERA WITH JUST SAVING IMAGE OR IMAGE PRINTING ON TICKET OPTIONS(CAN  
BE ACTIVATE OR DEACTIVATE FROM CPANEL)

CCTV CAMERA VIDEO RECORDING IN WEIGHBRIDGE SOFTWARE SCREEN(THIS VERSION IS  
AVAILABLE ACCORDING TO REQUIREMENTS).

ONE MS-EXCEL FILE SAP.XSL WILL BE CREATED ON EACH ENTRY TO SHARE THE  
SOFTWARE DATA WITH SAP ERP APPLICATION.

EASY BACKUP OF THE DATA WITH ONE CLICK ON BACKUP BUTTON YOU CAN SET THE  
BACKUP PATH ALSO.

UNLIMITED USERS CAN BE CREATED FOR EACH AND EVERY CLIENTS BY LOGGING AS  
ADMIN.

ADMIN CAN ONLY CHANGE INDICATOR SETTING AND GROSS WEIGHT UNLOCK KEY AS  
WILL AS TICKET UNLOCK BOX.

REPORTS:SUPPORTS BOTH DIRECT PRINT OR MS-EXCEL REPORTS

1.DATE WISE

2.CUSTOMER WISE

- 3.SUPPLIER WISE
- 4.SLIP WISE
- 5.MATERIAL WISE
- 6.USER REPORTS.
- 7.USER LOG REPORTS.

USAGE INSTRUCTIONS:

SYSTEM REQUIRMENTS:

- 1.WINDOWS 7,8,10
- 2.MS OFFICE 2007 AND MS EXCEL 2007 OR LATEST
- 3.COM PORT OR SERIAL PORT AND USB PORT
- 4.LASER OR DOTMATRIX PRINTER

DOWNLOAD THE EBIZ.ZIP FILE BY CLICKING ABOVE LINK AFTER DOWNLOAD COMPLETE UNZIP THE FILE AND INSTALL.

SOFTWARE DEFALUT INSTALLATION PATH C:\PROGRAM FILES\PROJECT1 YOU CAN CHAGE THIS PATH AT THE TIME OF INSTALLATION

AFTER INSTALLING RUN THE FILE EBIZ .EXE

userid:admin

password:demo

control panel password:demo

IN CONTROL PANEL YOU NEED TO SET COMPORT NO AND IN SETTING BOX CHANGE YOUR BAUDRATE EG:9600,N,8,1

NOW CHECK YOUR STRING IN HYPER TERMINAL TO ADD STRING STRING AND END STRING

EG:IF IN HYPERTERMINAL YOU WEIGHT SHOW !@#35625!@#

THEN YOUR START STRING IS 4 AND END STRING IS 5 (END STRING IS NO. OF DIGIT YOU WANT)

YOU WILL GET WEIGHT 35625

CHECK STRING LENGTH BUTTON IN CONTROL PANEL IS TO GET THE LENGTH OF THE STRING

WHEN YOU PRESS THIS CHECK STRING LENGTH BUTTON YOU WILL GET STRING LENGTH FROM ACTIVE COMPORT AND PORT WILL OPEN

TO STOP OR CLOSE THE PORT PUT CURSON ON STRING LENGTH TEXT BOX AND PRESS TAB .

YOU CAN ENTER LENGTH MANUALLY IF WEIGHT IS BLINKING IN SOFTWARE TO REMOVE SPACES.

IF STRING LENGTH IS 8 AND IF WEIGHT IS BLINKING YOU CAN REDUCE THE STRING LENGTH BY ENTERING MANUALLY.

IF YOU ARE USING IP INDICATOR YOU NEED TO SELECT OTHER OPTION GET WEIGHT USING EHTERNET PORT.

ENTER THE START OF THE STRING AND END STRING (NO .OF DIGITS YOU WANT)

YOU CAN CREATE USER BY ENTERING USER NAME PASSWORD IN CONTROL PANEL OR DELETE USER BY SELECTING USER AND PRESS DELETE

YOU CAN SELECT THE ADDITIONAL FIELDS FROM CPANEL ACCORDING TO YOU REQUIREMENTS.

AND PRESS UPDATE BUTTON.

GOTO TO WEIGHTMENT MENU AND SELECT WEIGHTMENT.

F3 FOR NEW ENTRY

F4 FOR CANCEL

F5 FOR FIND

F6 FOR OPEN PENDING LIST

F7 FOR EXIT

F1 FOR GETTING WEIGHT INTO GROSS BOX

F2 FOR GETTING WEIGHT INTO TARE BOX

Thanks & Regards

Moin Hamdani

+919512519502

ebiz infoserves

ALMOIN opp Suriawad Memon Jamat Khana Memonwad Porbandar Gujarat India

[www.ebizinfoserves.co.in](http://www.ebizinfoserves.co.in)

[info@ebizinfoserves.co.in](mailto:info@ebizinfoserves.co.in)